



Shadow Diffusion Guadalupa Floor Heater

Safety Instructions and Operation Manual 902118



Heat Outdoors
Unit 9, Stort Valley Industrial Estate
Stansted Road, Bishop's Stortford
Hertfordshire, United Kingdom
CM23 2TU

www.heat-outdoors.co.uk
01279 466500
info@heat-outdoors.co.uk

Contents

Brief Introduction	3
Important Information	3
Safety Instructions	4
Description of Parts	6
Assembly Instructions	7
Operation	9
Cleaning & maintenance	11
Storage	12
Technical Specification	12
Customer Service	12

Brief Introduction

Thank you for choosing our Shadow Diffusion Tower Heater. This instruction manual will provide you with valuable information necessary for the proper care and maintenance of your new product. Please take a few moments to thoroughly read the instructions and familiarise yourself with all the operational aspects of your new heater.

Important Information

Please carefully read all instructions provided before using this appliance. This heater must be installed and used as instructed.

This Operation Manual contains the important safety information, as well as some recommendations for the correct use, installation and maintenance of this appliance.

When operating this infrared heater be sure to observe necessary precautions as improper operation with disregard of these precautions may result in harm to health of the user, other people or objects.

Ensure to keep this manual along with your sales receipt, and if possible, cardboard package and packing material in case return of the unit is necessary.

- **Unpack the halogen heater making sure that all the items are present, there are no components left in the box and the heater head is free from any packing material.**
- **Using the detailed diagrams follow the steps to assemble your halogen heater.**
- **Do not connect the halogen heater to the electrical supply until the assembly is complete.**
- **Do not connect the halogen heater to the electrical supply if any of the components or the power cord is damaged in any way.**

Safety Instructions

Read these instructions before using.



WARNING

Potential fire risk if the heater is covered by any material or positioned close to curtains or other flammable materials.

- Only use the halogen heater on a firm solid horizontal area where all the feet on the base are in contact with the floor. (Should the heater be tilted or fall over the auto cut off switch will activate).
- Site the heater outside or in a large open area and well away from any obstructions such as branches or where the heater is near any objects that can be affected by heat, such as furniture, curtains or other inflammable objects (minimum distance 1 metre).
- **DO NOT** use near bath tubs, wash areas or swimming pools.
- **DO NOT** use in unventilated areas
- **DO NOT** use where gas, petrol, paint or other inflammable goods are stored.
- **DO NOT** push any items through, obstruct or cover the grill of the heater head.
- **DO NOT** position immediately above or below an electrical socket.
- **DO NOT** move when connected to an electrical supply and always wait for the patio heater to cool down before storing away.
- **DO NOT** touch the heater head when in use.
- **DO NOT** leave turned on and unattended especially when children and or animals are in the vicinity.
- The indication of the different positions of switches shall be visible from a distance of 1m.
- The marking concerning covering should be visible after the heater has been installed. It should not be placed on the back of portable heaters.
- The unit must be placed with a minimum clearance of 100cm to a wall and 30cm to the ceiling.
- The unit must be securely placed on a horizontal and flat surface.
- The unit operates at high temperature during operation. The unit stays hot for a period after shut down. Potential danger will occur when touching it during this period.
- Don't place the unit close to curtains and/or other flammable objects. Otherwise, there will be a danger of catching fire.
- Don't cover the unit with anything during operation or a short time after it's shut down.

- Don't wrap the power supply cord on the unit.
- The unit must be handled with care, and avoid vibration or sudden impact.
- The unit must be securely grounded during operation.
- If the unit gets damaged, it must be repaired by professional electricians.
- When the power supply cord is damaged, it must be replaced by an authorised agent or other professional to avoid danger.
- The unit must not be positioned under a socket.
- When assembling, keep clear from any board or flammable material.
- The unit must be not be operated by children or vulnerable people.
- Children and vulnerable people must be supervised at all times.
- It is not safe to install the unit by a swimming pool, in a bathroom or shower area.
- The unit is for household use only. It is not safe to use on a building site, greenhouse, barn or stable where there's flammable dust.
- The head of the unit is at a high temperature during operation. Unplug the unit and wait till it cools before cleaning.
- Don't use this unit in places where causticity or volatile air exists, i.e. dust, steam, gas, etc.
- Don't use this unit as a cloth, textile material or towel drier.
- Don't use this unit as a sauna heater.
- Don't use this unit as a room heater.
- Don't use this unit in a place of animal propagating and raising.
- Don't immerse this unit into water for cleaning.
- The unit should be plugged in a socket, which is easily visible and reachable.
- Two dark points may exist on the surface of the heating elements during the first few minutes after it is turned on. This is normal, and will not affect the performance of the unit.
- The unit contains a tilt switch that automatically turns off the appliance if knocked over.

Description of Parts




Assembly Instructions




Do not switch on the heater before assembly has been completed.


1. Position the main body of the heater onto a table to assemble the base.



2. When assembling the body of the heater, insert the four raised parts of Base B into the corresponding holes of Base A. There are two joints on Base B. Base B must be inserted into Base A until a "click" is heard.




3. Firmly fix the base with the bolt in the centre.



Operation

- During use, keep the heater at a safe distance of at least 100cm from inflammable objects (e.g. curtains) and from walls. (See diagram on right).
- Do not use the heater on uneven surfaces and on carpets.
- Should it fall, the tip over cut-off device under the base will automatically switch off the appliance.




After having inserted the plug into the power socket and pressed the I/O switch, the red POWER indicator and the green HIGH indicator will light up.

Use of the switch

START UP: Press the ON/OFF button. The green indicator HIGH (maximum heating) will light up. Press again to switch the heater off. The POWER indicator remains on until the plug has been removed.

HEAT SETTING: Press the H/L to set the heating mode:

- Minimum heating: 450 W (L)
- Maximum heating: 900 W (H)



Timer regulation

To set the timer, press the TIMER button until the required position has been reached, as shown by relative indicator lights.


Press the button again to turn off the timer, the indication light will switch off

Timer setting	0.5h = 30min	1h = 1 hour
	2H = 2 hours	4H = 4 hours

Operation of oscillation

By pressing the oscil button, the heater body oscillates at an angle of 80 degrees from right to left. The indication light will light up.

Press the button again to stop oscillation.



Cleaning & maintenance

Heater housing, grills and internal reflector

- Disconnect the appliance from the power supply system.
- After the appliance has cooled down, the housing can be wiped clean with a damp cloth.
- Do not touch the bulb element with your fingers. Stains can build up from contact and may cause malfunction of the bulb.
- Do not use any abrasive or hard cleaning products on any part of this heater.
- Do not immerse the appliance in water.
- Wait until the unit is completely dry before use.

Cleaning of heater lamp

- Disconnect the appliance from the power supply system.
- Wipe the lamp over with a damp cloth. Ensure no detergents or cleaning fluids are used as they may cause damage to the lamp coating.

<https://www.heat-outdoors.co.uk/help-desk/useful-articles/heater-and-lamp-maintenance.html>

Any maintenance or repairs should only be carried out by a qualified electrician if you're unsure how to do so. For further information and guidance, visit our online help articles and videos.

Disposal



In accordance with European Directive 2001/96/EG concerning used electrical and electronic appliances (waste electrical and electronic equipment – WEEE), please return any electrical equipment that you will no longer use to the collection points provided for their disposal.

This symbol indicates that the appliance cannot be treated as normal domestic trash, but must be handed to a collection point for recycling electric and electronic appliances.

Information concerning where the equipment can be disposed of can be obtained from your local authority.

Storage

If the heater will not be used for a long period of time, store it in a cool, dry location. To prevent dust and dirt build-up, use the original packaging to repack the heater.

Technical Specification

Ratings: 220-240V AC 50-60Hz

Power consumption: 900W

Dimensions: 85x30x32

Net weight: 2.8kg

Insulation: Class 1

Ingress Rating: IP54

Customer Service

- Repairs must be carried out by authorized specialists, thus ensuring electrical safety.
- Please contact us or a suitably qualified electrician.
- Improper repairs could lead to danger to the user.

Warranty does not cover damage of failure which results from alteration, accident, misuse, abuse, neglect, commercial use or improper maintenance. In line with our policy of continuous product development we reserve the right to change the product and documentation specifications without notice.



Heat Outdoors

Unit 9, Stort Valley Industrial Estate
Stansted Road, Bishop's Stortford
Hertfordshire, United Kingdom
CM23 2TU

www.heat-outdoors.co.uk
01279 466500
info@heat-outdoors.co.uk