



- 1.0 Mast holder only for shade mast made of steel or aluminium, shade mast diameter min 45mm, max. 90 mm
- 1.1 Open the strain fastener
- 1.2 Adjust the four screw bolts in the right position (according to the mast diameter)
- 2.0 Mount the mast holder bracket around the mast, cable gland down side
- 2.1 Hinge the strap
- 2.2 Close the strain fastener
- 3.1 Fasten all four screw symmetrical
- 4.1 Tighten with the wrench all four screws. The mast holder should not be move.